




MAELSTROM120 Series
User manual

www.gamstorm.com



1 Heatsink set	1 pc	2 120mm Fan	1 pc	3 Screw(1)	4 pcs	4 Screw(2)	4 pcs	5 Back Plate	1 pc
6 Screw Bolt	4 pcs	7 Insulative cushion	4 pcs	8 Screw(3)	4 pcs	9 Mounting Bracket(Intel)	2 pcs	10 Mounting Bracket(AMD)	2 pcs
11 Double-screw Bolt (For LGA20XX only)	4 pcs	12 Nut	4 pcs	13 Double-screw Bolt (For AM4 only)	4 pcs	Well note: Please keep cooling block at the direction which has no interference with the neighboring parts.			



INTEL
LGA1366
LGA1156
LGA1155
LGA1151
LGA1150

Well note: please follow the right installation direction as left draft

AMD
AM4
AM3+
AM3
AM2+
AM2
FM2+
FM2
FM1

INTEL
LGA20XX

INTEL/AMD

1. CPU FAN1/FAN2
2. Prior to CPU FAN1/FAN2/OPT, and then PWR/CHA/SYS FAN




水元素120系列
使用说明书

www.gamstorm.com



1 散热器主体	1 个	2 120mm风扇	1 个	3 螺丝(1)	4 个	4 螺丝(2)	4 个	5 背板	1 个
6 螺柱	4 个	7 绝缘胶垫	4 个	8 螺丝(3)	4 个	9 Intel转接架	2 个	10 AMD转接架	2 个
11 双头螺栓(LGA20XX专用)	4 个	12 螺母	4 个	13 双头螺栓(AM4专用)	4 个	注意: 请在安装前确认主体与CPU周围电子元件干涉情况来决定安装方向			



INTEL
LGA1366
LGA1156
LGA1155
LGA1151
LGA1150

警告: 请按照左侧图示安装

AMD
AM4
AM3+
AM3
AM2+
AM2
FM2+
FM2
FM1

INTEL
LGA20XX

INTEL/AMD

1. 连接在CPU FAN1/FAN2
2. 连接在CPU FAN1/FAN2/OPT; PWR/CHA/SYS FAN均可