





MAELSTROM
User manual

www.gamersstorm.com



1 2 3 4 5 6 7 8 9 10 11 12 13 14

1	Heatsink set	1 pc	2	120mm Fan	1 pc	3	Screw(1)	4 pcs	4	Screw(2)	4 pcs	5	Back Plate	1 pc
6	Screw Bolt	4 pcs	7	Insulative cushion	4 pcs	8	Screw(3)	4 pcs	9	Mounting Bracket(Intel)	2 pcs	10	Mounting Bracket(AMD)	2 pcs
11	Double-screw Bolt (For LGA2011 only)	4 pcs	12	Nut	4 pcs	13	Metal Logo Sticker	1 pc	14	Double-screw Bolt (For AM4 only)	4 pcs	Well note: Please keep cooling block at the direction, which has no interference with the neighboring parts.		



INTEL
LGA1366
LGA115X

1. CPU FAN1/FAN2
2. Prior to CPU FAN1/FAN2/OPT, and then PWR/CHA/SYS FAN

AMD
AM4
AM3+
AM3
AM2+
AM2
FM2+
FM2
FM1

INTEL
LGA20XX

INTEL/AMD




水元素
使用说明书

www.gamersstorm.com



1 2 3 4 5 6 7 8 9 10 11 12 13 14

1	散热器主体	1个	2	120mm风扇	1个	3	螺丝(1)	4个	4	螺丝(2)	4个	5	背板	1个
6	螺柱	4个	7	绝缘胶垫	4个	8	螺丝(3)	4个	9	Intel转接架	2个	10	AMD转接架	2个
11	双头螺栓(LGA2011专用)	4个	12	螺母	4个	13	金属标贴	1个	14	双头螺栓(AM4专用)	4个	注意: 请在安装前确认主体与CPU周围元件干涉情况决定安装方向		



INTEL
LGA1366
LGA115X

AMD
AM4
AM3+
AM3
AM2+
AM2
FM2+
FM2
FM1

INTEL
LGA20XX

INTEL/AMD