

AK620 G2 Series


Wood Grain Top Cover CPU Cooler

AK620 G2

AK620 G2 WH

INTEL-LGA1851/1700/1200/1151	1
AMD-AM5/AM4	8
Connection	16
Instruction of the Software	17

INTEL & AMD




A

x1




B

x2



C

x1



D

x4




E

x2




F

x2



G

x4




H

x4




I

x4




J

x1






K




x1





L



x1


















A





























Connection



4-PIN/CPU_FAN/CPU_OPT

Instruction of the Software




0 offset


For the AK620 G2's base mounting bracket, positional adjustment is available.

- For Intel LGA1851 CPUs: Offset the cooler 5mm upward for optimal performance.
- For AMD AM5 CPUs: Offset the cooler 5mm downward for optimal performance.

If compatibility issues arise at this offset position (e.g., clearance conflicts with the GPU), adjust the bracket to the standard position (0 offset).



LGA1851 Offset
Schematic Diagram



AM5 Offset
Schematic Diagram

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr+6)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
散热片	○	○	○	○	○	○
塑胶	○	○	○	○	○	○
硅胶	○	○	○	○	○	○
集成电路	○	○	○	○	○	○
零件包	○	○	○	○	○	○


 本表格依据SJ/T 11364的规定编制。
 环保使用期限标识表示产品在正常工作温度和湿度等条件下的环保使用年限为10年。
 ○:表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。
 ×:表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求,
 且因技术发展水平限制而无成熟方案替代,均符合欧盟RoHS法规环保指令。

