



INSTALLATION GUIDE

This installation guide is applicable for FROSTWIN LED Series.



FROSTWIN LED SERIES

PRODUCT SCHEMATIC DRAWING

1 Back Plate	1pc	2 Screw Bolt	4pcs	3 Nut A	4pcs	4 Nut B	4pcs	5 INTEL Clip	2pcs
6 AMD Clip	2pcs	7 Thermal paste	1pc	8 Double-screw Bolt	4pcs	9 Heatsink set	1pc		

INTEL
LGA1366
LGA1156
LGA1155
LGA1151
LGA1150

AMD
AM4
AM3+
AM3
AM2+
AM2
FM2+
FM2
FM1

INTEL
LGA2011
/2011-v3



安装说明书

此说明书适用于九州风神小露塔。



小露塔

产品示意图

1 背板	1个	2 六角螺钉	4个	3 平垫圈	4个	4 平垫圈	4个	5 INTEL扣具	2个
6 AMD扣具	2个	7 导热膏	1个	8 双头螺钉	4个	9 主体	1个		

INTEL
LGA1366
LGA1156
LGA1155
LGA1151
LGA1150

AMD
AM4
AM3+
AM3
AM2+
AM2
FM2+
FM2
FM1

INTEL
LGA2011
/2011-v3