




INSTALLATION GUIDE

This installation guide is applicable for ICE BLADE PRO v2.0 Series.



ICE BLADE PRO v2.0
PRODUCT SCHEMATIC DRAWING

1	Nut	4 pcs	2	Insulation Pillar	4 pcs	3	Screw Bolt	4 pcs	4	Mounting Bracket(Intel)	2 pcs	5	De-Vibration Buckle	4 pcs
6	Retention Plate	1 pc	7	Back Plate	1 pc	8	Mounting Bracket(AMD)	2 pcs	9	Insulating Washer (For LGA775 only)	1 pc	10	Double-screw Bolt (200X)	4 pcs
11	Wire Clip	4 pcs	12	Thermal Grease	1 pc	13	De-vibration Buffer	8 pcs	14	Fan	1 pc	15	Heatsink set	1 pc
16	Double-screw Bolt (AM4)	4 pcs												

INTEL
LGA1366
LGA1156
LGA1155
LGA1150
LGA775

AMD
AM4
AM3+
AM3
AM2+
AM2
FM2+
FM2
FM1


INTEL
LGA20XX

www.deepcool.com



安装说明书

此说明书适用于九州风神冰刃至酷版系列产品。



冰刃至酷版
产品示意图

1	螺母	4个	2	绝缘柱	4个	3	螺钉	4个	4	Intel转接架	2个	5	减震扣	4个
6	扣具	1个	7	背板	1个	8	AMD转接架	2个	9	绝缘垫(LGA775专用)	1个	10	双头螺栓-200X	4个
11	钢丝扣	4个	12	针管导热膏	1个	13	减震垫	8个	14	120mm风扇	1个	15	散热器主体	1个
16	双头螺栓-AM4	4个												

INTEL
LGA1366
LGA1156
LGA1155
LGA1150
LGA775

www.deepcool.com

AMD
AM4
AM3+
AM3
AM2+
AM2
FM2+
FM2
FM1

INTEL
LGA20XX