




INSTALLATION GUIDE

This installation guide is applicable for NEPTWIN Series



NEPTWIN
PRODUCT SCHEMATIC DRAWING

1	Nut	4 pcs	2	Insulation Pillar	4 pcs	3	Screw Bolt	4 pcs	4	Mounting Bracket(Intel)	2 pcs	5	De-Vibration Buckle	4 pcs
6	Retention Plate	1 pc	7	Back Plate	1 pc	8	Mounting Bracket(AMD)	2 pcs	9	Insulating Washer (For LGA775 only)	1 pc	10	Double-screw Bolt (For LGA20XX only)	4 pcs
11	Thermal Grease	1 pc	12	Heatsink set	1 pc	13	Double-screw Bolt (For AM4 only)	4 pcs						

For LGA775 only

LGA 1366

LGA 115X

Back plate installation (Intel)

AMD

AM4

AM3+

AM3

AM2+

AM2

FM2+

FM2

FM1

Intel


LGA20XX

www.deepcool.com



安装说明书

此说明书适用于九州风神大霜塔系列。



大霜塔
产品示意图

1	螺母	4个	2	绝缘柱	4个	3	螺柱	4个	4	Intel转接架	2个	5	减震扣	4个
6	扣具	1个	7	背板	1个	8	AMD转接架	2个	9	绝缘垫(LGA775专用)	1个	10	双头螺栓(LGA20XX专用)	4个
11	导热膏	1个	12	散热器主体	1个	13	双头螺栓(AM4专用)	4个						

Intel

LGA1366

LGA1156

LGA1155

LGA1151

LGA1150

LGA775

www.deepcool.com

AMD

AM4

AM3+

AM3

AM2+

AM2

FM2+

FM2

FM1

Intel

LGA20XX